

IEC CENTRA[®]-8
GENERAL PURPOSE
CENTRIFUGE

IM220

INSTRUCTION MANUAL

August 1985

MODEL 2476

50/60 HZ
120 VAC

digital,
bench model

MODEL 2477

50/60 HZ
100/120/200/220/240 VAC

*purchased from Block Scientific
473 South Dean St
PO Box 5267
Englewood, N.J.*

*201-894-2330
Peter Will
Brian Griffith*

WARNING

**DO NOT ATTEMPT TO OPERATE THIS CENTRIFUGE
BEFORE THOROUGHLY READING THE OPERATOR'S SECTION**



INTERNATIONAL EQUIPMENT COMPANY

A DIVISION OF DAMON

300 SECOND AVENUE, NEEDHAM HTS., MA 02194, TEL: (617) 449-0800
TELEX: 92-2499 INTLEQUIP NEDM CABLE: INTERCO-BOSTON

785 800-843-1113 ask for

Kathryn




TABLE OF CONTENTS

Para.	Title	Page	Para.	Title	Page
1.0	GENERAL DESCRIPTION	1-1	4.0	SERVICE	4-1
1.1	Purpose of Manual	1-1	4.1	General	4-1
1.2	Description of Centrifuge	1-1	4.2	Operating Theory	4-1
1.3	Specifications	1-1	4.2.1	Power Circuit	4-3
1.4	Warranty	1-3	4.2.2	Motor Circuit	4-4
1.5	Ordering Information and Factory Returns	1-3	4.2.3	Motor Control Board	4-6
1.6	Registration of Instrument	1-3	4.2.4	Tach/Time Board	4-6
2.0	INSTALLATION	2-1	4.2.5	Controls and Circuit Devices	4-6
2.1	General	2-1	4.2.5.1	Start Switch S1	4-6
2.2	Receiving Inspection	2-1	4.2.5.2	Brake Switch S2	4-10
2.3	Unpacking and Inspection Procedure	2-1	4.2.5.3	TIME Switch S3	4-11
2.4	Setup and Installation	2-1	4.2.5.4	STOP Switch S4	4-11
2.4.1	Preliminary Checkout	2-1	4.2.5.5	TIME Set Switch S5	4-12
2.4.2	Installation Checkout	2-4	4.2.5.6	SPEED Select Switch S6	4-12
3.0	OPERATION	3-1	4.2.5.7	Imbalance Switch S7	4-12
3.1	General	3-1	4.2.5.8	Cover Switch S8	4-12
3.2	Description of Operation	3-1	4.2.5.9	Fan Relay K1	4-13
3.2.1	Control Panel	3-1	4.2.5.10	Hall Effect Sensor	4-13
3.2.2	Data Plate/Power Cord/Fuse	3-3	4.3	Troubleshooting	4-14
3.3	Operational Precautions	3-3			
3.4	Operating Procedure	3-5		ILLUSTRATIONS	
3.4.1	Opening the Cover	3-5	Figure	Title	Page
3.4.2	Installing the Rotor	3-5	1-1	Outline Dimensions	1-4
3.4.3	Loading the Rotor	3-5	2-1	Unpacking	2-2
3.4.4	Programming the Run Cycle	3-6	2-2	Centra-8 Centrifuge	2-2
3.4.5	Starting the Run Cycle	3-6	2-3	Air Circulation	2-5
3.4.6	Stopping the Run Cycle	3-6	3-1	Control Panel	3-2
3.4.7	Changing Modes During Operation	3-8	3-2	Installing Rotor	3-4
3.4.8	Determination of RCF	3-8	3-3	Guard Bowl Removal	3-11
3.4.9	Removing the Rotor	3-8	3-4	Brush Replacement	3-12
3.5	Care and Cleaning of IEC Rotors and Structural Accessories	3-8	3-5	Main Fuse Replacement	3-13
3.5.1	Corrosion	3-8	4-1	System Functional Diagram	4-1
3.5.2	Inspection	3-8	4-2	System Schematic Diagram	4-2
3.5.3	Prevention	3-8	4-3	Power Circuit	4-3
3.5.4	Drying	3-9	4-4	Motor Circuit	4-4
3.5.5	Corrosion Removal	3-9	4-5	Motor and Motor Fan Functional Diagram	4-5
3.6	Cleaning the Centrifuge	3-9	4-6	Motor Control Board Circuit	4-6
3.7	Cover Interlock Mechanical Safety Bypass	3-11	4-7	Tach/Time Circuit	4-7
3.8	Guard Bowl Removal/ Replacement	3-11	4-8	System Wiring Diagram	4-8
3.9	Motor Brush Removal/ Replacement	3-12	4-9	Start Switch S1 Wiring Diagram	4-10
3.10	Commutator Inspection	3-12	4-10	Brake Switch S2 Wiring Diagram	4-10
3.11	Fuse Replacement	3-13	4-11	Time Switch S3 Wiring Diagram	4-11
			4-12	STOP Switch S4 Wiring Diagram	4-11
			4-13	Imbalance Switch S7 Wiring Diagram	4-12
			4-14	Cover Switch S8 Wiring Diagram	4-13
			4-15	Fan Relay K1 Wiring Diagram	4-13
			4-16	Hall Effect Sensor Wiring Diagram	4-13
			4-17	Display P.C. Board Schematic	4-16

TABLE OF CONTENTS (Continued)

TABLES		
Table	Title	Page
1-1	Specifications	1-2
3-1	Nomograph	3-7
3-2	IEC Centra-8 Centrifuge Accessory Combinations, Speed/Force Tables, and Related Data	Follows 3-10
4-1	Troubleshooting Chart	4-15

1.0 GENERAL DESCRIPTION

1.1 Purpose of Manual

This manual provides installing, operating and servicing instructions for the Model Centra®-8 Centrifuge manufactured by the International Equipment Company (IEC), a Division of Darnon Corporation.

1.2 Description of Centrifuge

The Centra-8 is a general purpose, digital benchtop centrifuge designed for use in the medical, industrial, and scientific laboratory to perform separations by centrifugal force. The centrifuge will accommodate tubes, bottles, and blood bags. It is registered as a device in accordance with FDA Regulations governing distribution and use of such products.

The Centra-8 is designed for 120 VAC, 50/60 Hz (Catalog No. 2476), and 100, 120, 200, 220 or 240 VAC, 50/60 Hz (Catalog No. 2477) operation.

A cabinet supports the centrifuge chamber, which is comprised of a removable corrosion-resistant, stainless-steel guard bowl. A protective steel liner surrounds the sides of the guard bowl. The guard bowl is electrically grounded through a three-pin connector, which also serves as an interlock. When the connector is unplugged, the motor circuit is interrupted. A rotor drive assembly is mounted to the cabinet base through the center of the guard bowl. The drive assembly employs a permanent magnet motor. The motor has permanently - sealed, self-lubricating ball bearings. Motor brushes are replaceable from within the chamber.

A dynamic electric brake provides control of deceleration of the drive assembly.

A counter-balanced cover assembly forms the top section of the chamber. The latch control knob on the front panel and latch assembly in the cabinet housing provide an interlock. This interlock prevents opening the cover of the centrifuge when the rotor is

turning or, if the cover is not completely closed and latched, prevents activation of the centrifuge. —

A removable control panel is located at the lower front of the cabinet. The controls on this panel are used to apply electrical power and to set the speed, timing, braking, and the run-cycle starting and stopping modes of the centrifuge.

An out-of-balance switch actuates when the rotor imbalance is excessive. When this switch is actuated, IMBALANCE is displayed on the front panel and the rotor will decelerate to a stop. The imbalance switch, the guard-bowl interlock connector, a fan relay, a latch switch, a latch solenoid, and a motor control and logic printed circuit (PC) board, with a brake resistor, are located within the cabinet housing.

The remaining major electrical and electronic components are located on the control panel along with a tachometer/timer display PC board. These are accessible after the control panel assembly is removed.

A fuse and a power cord are also part of the cabinet assembly.

Most of these parts have connectors to facilitate servicing, or replacement.

Inlet and outlet vents in the cover provide chamber cooling. Inlet and outlet vents, coupled with a blower fan assembly within the cabinet, provide drive-assembly motor cooling.

Four suction cup feet, mounted on the base of the unit, increase stability.

1.3 Specifications

Table 1-1 provides a quick-reference listing of the major specifications.

**TABLE 1-1
SPECIFICATIONS**

*Maximum Speed of Rotation	
Angle (811a) Rotor, W/356 Shields	5800 RPM
Horizontal (921) Rotor W/366 Trunnion Rings and 369 Carriers	4800 RPM
*Maximum Relative Centrifugal Force (RCF)	
Angle (845a) Rotor, W/2944 Bottles	5060 x g
Horizontal (921) Rotor, W/310 Trunnion Rings and 303 Shields	4160 x g
*Maximum Volume	
Angle (845a) Rotor w/2944 Bottles	1920 ml (8 x 240 ml)
Horizontal (216) Rotor w/2272 Bottles	3000 ml (4 x 750 ml)
*Maximum Tube Capacity	
Angle (822a) Rotor w/320 Shields and 7249 Adapters	84 Tubes (1 ml)
Horizontal (216) Rotor w/5737 Adapters	148 Tubes (3-5 ml)
Speed Control	
Range	500 - 5900 RPM
Increments	100 RPM
Accuracy	± 10 RPM
Speed Display	
Range	1 - 5900 RPM
Increments	1 RPM
Timer	
Range	1 - 59 Min. or Hold Position
Increments	1 Min.
Type	Quartz Crystal Controlled
Braking System	
Dynamic Electric	
Drive Assembly Motor	
0.6 HP @ 5000 RPM	
Power Requirements: Catalog No. 2476	
120 VAC ± 10%, 50/60 Hz, 12 Amps.	
Catalog No. 2477	
100,120, ±10%, 50/60 Hz, 12 Amps.	
200,220,240 ± 10%, 50/60 Hz, 8 Amps.	
Fuse	
12 Amps. (8 Amps. for 200, 220 or 240 VAC machines)	
Power Consumption	
700 Watts, Max., Operating	
Total Heat Produced	
2150 BTU/Hr., Operating	
Net Weight: Catalog No. 2476	
67.13 kg (148 lbs.)	
Catalog No. 2477	
74.39 kg (164 lbs.)	
Shipping Weight: Catalog No. 2476	
78.93 kg (174 lbs.)	
Catalog No. 2477	
86.18 kg (190 lbs.)	
Centrifuge Dimensions:	
Height (with cover open)	852 mm (33.54 in.)
Height (with cover closed)	386 mm (15.20 in.)
Width	578 mm (22.75 in.)
Depth	574 mm (22.60 in.)
Inside Diameter of Guard Bowl	438 mm (17.25 in.)
Packing Case Dimensions:	
Height	572 mm (22.50 in.)
Width	711 mm (28.00 in.)
Depth	914 mm (36.00 in.)
Volume	0.37 m ³ (13.13 ft. ³)

The Centra-8 is shipped with a rotor locking nut wrench, Part No. 1787, and Instruction Manual, IM-220.

*Refer to Table 3-2 for complete accessories combinations, relative centrifugal forces (RCF), speed ranges, and related data.

1.4 Warranty

International Equipment Company (IEC) warrants that it will repair or replace, free of charge to an Authorized Dealer of IEC any instrument which fails within one (1) year after delivery to the original customer because of defective material or workmanship, provided it does not fail under the exceptions and conditions specified in the warranty given with the instrument. Such exceptions and conditions include, but are not limited to, failure of parts due to natural wear, accident, neglect or operation in a manner not prescribed in the operating instructions supplied with the instrument. The foregoing expresses IEC's sole warranty with respect to the instrument. THIS WARRANTY IS MADE IN LIEU OF ANY AND ALL OTHER WARRANTIES AND ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED AND EXCLUDED. IEC and its Authorized Dealers will not be liable for consequential damages, loss or expense arising from the improper use of the instrument. IEC will not honor any other warranty given by the Authorized Dealer which is different from the warranty given by IEC. This warranty is not assignable and is operative only in favor of the original customer to whom this warranty is delivered.

DEALER OBLIGATION UNDER WARRANTY

Customer requesting service for an instrument during the period covered by warranty should receive a response, within a 48-hour period, from the Authorized Dealer who sold the instrument. If this obligation is not met and the customer so advises IEC, such Authorized Dealer will be notified of, and responsible for, the action taken, and expense incurred, by IEC in satisfying the customer.

DISCLAIMERS AND EXCLUSIONS

The Installation, Operation and Service Manual supplied with this instrument includes a service trouble-shooting chart. However, you are under no obligation to locate or remedy any service problem. You hereby release and forever discharge IEC, its successors, assigns, subsidiaries, affiliates, officers, agents, and employees from any and all claims, demands and liabilities in law or in equity, of any nature, based upon, arising out of, or resulting from locating, remedying or attempting to locate or remedy any service problem. Should service be required, contact the dealer from whom you purchased this instrument to obtain service by factory trained personnel.

The information included in this Installation, Operation and Service Manual is believed adequate for the operation and intended use of this instrument. If the instrument is to be used for any purpose exceeding or deviating from the capabilities specified herein, then written confirmation or acceptability for such purpose should be obtained from IEC. Failure to do so will affect the warranty, and IEC will not guarantee any results nor assume any obligation or liability arising from such confirmed action.

1.5 Ordering Information and Factory Returns

To obtain service and/or replacement parts under warranty, you should contact the authorized IEC dealer from whom you purchased your instrument, or write directly to IEC, 300 Second Avenue, Needham Heights, Massachusetts 02194, Attention: Service Manager. Your correspondence must include the model and serial number of your instrument, the date of its delivery, and the name of the dealer from whom you purchased it. IEC will not accept goods returned without proper authorization. A "Returned Goods Authorization" (RGA) must be obtained through a dealer and accompany the prepaid return shipment.

Center for 1014x45000 per 1012000000
To obtain service and/or replacement parts not under warranty, or to order additional accessories, you may contact any authorized IEC dealer.

NOTE: In the event you wish to return the machine or any part, you must comply with the following

1. If the instrument or any part has been exposed to, or used to process, dangerous pathogenic or radioactive material, you are required to decontaminate the instrument or part being returned to insure there is no radioactivity or harmful bacteria present and to advise us accordingly.

2. Decontaminate the instrument or any part that may have accumulated blood or any other chemical deposits by using standard laboratory procedures. Should this instrument or any part be received in a condition we consider to be a potential biological hazard to our personnel, it will be returned to you unrepaired, at your expense.

1.6 Registration of Instrument

For registration purposes please fill out the Warranty Registration/Installation Report form supplied with the instrument. Return the completed form to IEC.




Figure 1-1 Outline Dimensions

2.0 INSTALLATION

2.1 General

The Centrifuge is shipped in a special carton designed to protect it against normal shipping hazards. Installation of the centrifuge includes an initial inspection of the carton before acceptance from the shipper, moving the carton to the operating location or incoming inspection area, unpacking, preliminary check-out, and installation for use.

2.2 Receiving Inspection

Before signing the delivery receipt and accepting the shipment, inspect the shipping carton for any signs of mishandling, such as broken or dented sides. Damage to the carton must be noted and a written statement made on the delivery receipt before signing, describing the nature of the damage. A normal or undamaged carton does not necessarily ensure that the contents have not been damaged during shipping. If mishandling, or damage, is suspected, contact the office of the carrier so that a representative may witness the unpacking. The centrifuge and other contents of the carton should be carefully examined as the unpacking proceeds. Any damage discovered, which can be attributed to mishandling or shipping damage, should be documented and a signed inspection report should be furnished to the shipping company. IEC is not responsible for damage incurred in transit.

2.3 Unpacking and Inspection Procedure

These instructions may be found on the shipping carton also.

CAUTION: THE UNIT WEIGHS OVER 100 LBS. (45.36 kg). UNPACKING AND INSTALLATION REQUIRES THE SERVICE OF TWO PEOPLE AND A HAND TRUCK OR A ROLLER LIFT.

Refer to Figure 2-1

1. Move the carton to the intended operating location, or a convenient area, for inspection. Keep all shipping documents.

2. Open the top of the carton and remove all accessible packing material and shipping supports. Inspect the centrifuge for obvious damage; if none, proceed.

3. With a partner, remove the centrifuge from the carton by reaching down inside the carton, grasping and lifting the centrifuge out of the carton. Save the carton and shipping material for possible re-use.

2.4 Setup and Installation

CAUTION: THESE PROCEDURES ARE TO BE COMPLETED BY QUALIFIED PERSONNEL ONLY. DO NOT ATTEMPT TO OPERATE THIS CENTRIFUGE BEFORE THOROUGHLY READING THIS MANUAL.

Refer to Figure 2-2

2.4.1 Preliminary Checkout

This procedure is used to ensure that the electrical line-voltage outlet is compatible with the electrical requirements of the centrifuge. Ideally the centrifuge should have its own separate branch circuit so that line load variations will be minimized. The wall outlet must be an AC, three-wire, grounded, single-phase circuit located within six feet of the centrifuge. The outlet should be easily accessible to allow the power line cord to be quickly disconnected.

Check the electrical requirements (voltage and frequency) shown on the dataplate, located on the left side of the centrifuge. Use an AC voltmeter to measure the voltage at the power outlet that the centrifuge power line cord will be plugged into. Check that the line voltage at the outlet is the same as the voltage shown on the dataplate.




Figure 2-1 Unpacking




Figure 2-2 Centra-8 Centrifuge

Check with your power company as to line frequency also shown on the dataplate.

Proceed as follows:

1. Catalog No. 2476: 120 VAC, 50/60Hz Instrument. Line voltage must be between 108 VAC and 132 VAC. If outside these limits, an external voltage step-up or stepdown transformer will be required.

2. Catalog No. 2477: 100, 120, 200, 220 or 240 VAC, 50/60Hz Instrument. Line voltage must be within the limits shown below:

Line Voltage (VAC)	Limits (VAC)
100	90 - 110
120	108 - 132
200	180 - 220
220	198 - 242
240	216 - 264

If outside these limits, an external voltage step-up or step-down transformer will be required. Line frequency must not be below 48 Hz.

CAUTION: OPERATION BELOW 48 Hz COULD AFFECT SPEED SETTINGS AND RESULTS, AND WILL VOID THE WARRANTY.

Note that fluctuations in line voltage as well as frequency will alter maximum rotor speeds with respect to the values listed in the Speed and Force Table of this Manual. If the line voltage and frequency are suitable for your centrifuge, you are ready to proceed to the installation checkout.

2.4.1.1 Electrical Connections

Catalog No. 2476 instruments do not require any electrical connections other than to plug the unit into the correct power outlet.

However, Catalog No. 2477 instruments are shipped from the factory for 240VAC, 50/60 Hz operation with an 8 Amp main power line fuse.

Therefore, for operation with either 100, 120, 200 or 220 VAC, 50/60 Hz operation, a single brown wire, #128, must be moved from its 240V tap to the appropriate tap.

Also, in 100V and 120V applications, a 12 Amp fuse and its label must replace the 8 Amp main power line fuse and its label. The 12 Amp fuse and label are part of the spare parts kit which is attached within the base assembly of the unit.

If the instrument is a Catalog No. 2477, make the following changes:

- Open the cover as described in Paragraph 3.7.
- Remove the guard bowl as described in Paragraph 3.8.
- Locate the auto transformer T1, directly behind the drive motor and shown in Figure 2-2.
- Locate the terminal strip on the top of T1 shown in Figure 2-2.
- The leads from T1 go directly to the top row of terminal screws on the strip. **DO NOT ATTEMPT TO CHANGE THESE LEADS.** The change is to be made on the bottom row of screws.
- Move the brown wire, #128, from the 240 terminal (the one closest to the rear of the unit) to the appropriate terminal. **NOTE:** If the input voltage is 120V there will be another wire on the terminal. Be sure to note its number and to re-attach it together with wire #128.
- Replace the 8 Amp line fuse and label with the 12 Amp fuse and label.
- Replace the guard bowl as described in Paragraph 3.8.




Figure 2-2A International (2477) Auto Transformer Connections

2.4.2 Installation Checkout

Perform the installation checkout procedures as listed below. Refer to Section 3.0 OPERATION, and Figure 3-1 as needed. With no, or with improper, operation at any of these checkout steps, consult your authorized IEC dealer, or see the troubleshooting chart in this manual. See also, the Warranty in Paragraph 1.4.

1. Push the Power switch to the OFF position. (Indicator lamp goes off.)

2. Set the RPM control and the Time control to zero and the Brake control to the OFF position.

3. Place the centrifuge on a firm flat, clean bench or table which is substantial in construction, and is permanently affixed to the wall and/or floor. Leave six inches of free space around the unit.

NOTE: To assist in moving the centrifuge into its final location on the table, or bench, place paper, or cardboard, under each suction cup foot. Slide the centrifuge into position. Lift each side, in turn, to remove the paper or cardboard.

The centrifuge base assembly has four mounting holes which allow it to be permanently mounted to a bench or table. IEC recommends this permanent mounting installation, which is a requirement in some locations. Figure 2-3 shows the four mounting hole dimensions.

CAUTION: ENSURE THAT THE VENTS ARE NOT BLOCKED, AS THIS WILL IMPAIR VENTILATION OF THE CENTRIFUGE.

4. Check that all controls are in the zero or OFF position. Plug the power cord into the correctly-rated power outlet. Set the Power switch to ON. The Power and the Stop indicators will light.

5. Open the cover by turning the latch knob clockwise (CW) one-quarter turn.

6. Remove the rotor by turning the shaft hex nut CCW using the rotor wrench, IEC Part No. 1787, supplied with the centrifuge.

7. Install any appropriate IEC rotor with a full complement of properly-balanced accessories.

8. Use the IEC Part No. 1787 wrench to TIGHTEN THE HEX NUT. Close and latch the cover by turning the latch knob one-quarter turn CCW.

9. Set the Speed control at the maximum listed speed for the rotor used. Refer to the Speed and Force and Accessory Table, Table 3-2.

10. Set the Timer to the Hold position.

11. Set the rotor Brake control to the ON position.

12. Push the Start button. The Stop indicator will go "off" and the Start light will go "on" as the rotor accelerates. Try to open the cover at this time by turning the latch knob CW to check the safety cover interlock. The cover should not open. Set the Timer to the Time position. Set the Timer to 5. Push the Start button. Observe the Speed indicator for acceleration. Use a stopwatch or a clock to check the accuracy of several different Timer settings.

13. Allow the Timer to stop the run.

14. When the Stop indicator lights, set the Timer to Hold. Push the Start button.

15. Allow the motor to reach the same preset speed and to stabilize. Set the Brake control to OFF, push the Stop button and record the coast period. The Stop indicator will light when the motor stops. Push the Start button.

16. Allow the motor to reach the same pre-set speed and to stabilize again. Set the brake control to ON. Push the Stop button and record the deceleration period. This should be approximately 1/3 the coast period.

If all of the preceding checks appear normal, then the checkout procedure is complete.

NOTE: If it is desired to relocate the centrifuge: ALWAYS remove the rotor before attempting to move the centrifuge; otherwise the motor drive shaft may be bent or damaged.




Figure 2-3 Air Circulation

3.0 OPERATION

3.1 General

This section contains instructions for the operation of the centrifuge and is intended to acquaint the user with the various controls, indicators, and operating characteristics of the instrument. Table 3-1 is a nomograph for computing relative centrifugal force (RCF).

3.2 Description of Operation

Centrifuge operation normally involves: Applying power, opening the cover, installing a rotor, installing a balanced load in the rotor, selecting the desired speed and timing modes, closing the cover, starting the run cycle, terminating the run cycle (unless the timing function has been selected, in which case the run automatically terminates at the end of the timed duration), opening the cover, and removing the rotor. The following paragraph describes the controls involved in operation.

3.2.1 Control Panel

All of the controls and indicators necessary to operate and monitor the centrifuge are located on the control panel at the lower front of the instrument, and are shown in Figure 3-1.

1. Power Switch/Indicator

This two-position, rocker switch/indicator is used to control power to the instrument. The top of the rocker section of the switch illuminates when in the ON position. Set the switch to OFF when the instrument is not in use.

2. Speed (RPM) Select Switch/Indicator

The first two thumbwheels of this four-thumbwheel switch are used to select any rotor speed from 500 to maximum RPM in 100 RPM increments. After setting the desired speed, use the Speed indicator for ascertaining the actual speed. Speed may be reset any time before or during a run cycle.

3. Speed (RPM)/Indicator

This initially blank, red indicator shows the actual rotor speed.

4. Time/Hold Mode Switch/Indicator

This alternate-action, pushbutton switch is used to select the hold (untimed) mode for runs exceeding 59 minutes, or when timing is not desired; or the timed (up to 59 minutes) mode of operation. When the button is depressed (Hold position) the yellow-indicator lights. If timing is desired, depress the button again. The yellow indicator does not light in the timed position.

5. Timer (Minutes) Setting Switch

This dual thumbwheel switch is used with the Time/Hold mode switch to select a timed run of up to 59 minutes.

6. Set and Countdown Time/Indicator

This initially blank, red indicator initially shows the set timed period then it shows the time remaining.

7. Brake Switch/Indicator


This alternate-action pushbutton switch is used to select the rotor-braking mode when desired. When the button is depressed the yellow indicator lights and the electric dynamic brake is energized. The rotor will stop in approximately one-third of the coasting (no brake) time.

When set to the OFF (non-depressed) position there is no braking force applied to the drive motor and the rotor will coast freely to rest.

Coasting and braking time depends on the rotor, load and speed.

8. Start Run, Start Reset Countdown Timer Switch/Indicator

This momentary-contact pushbutton switch is used to begin the run cycle after the speed, time and braking modes have been selected and the cover is closed and latched.



- | | |
|-------------------------------------|--|
| 1. Power Switch/Indicator | 8. Start Run, Start/Reset Countdown Timer Switch/Indicator |
| 2. Speed (RPM) Select Switch | 9. Stop-Run/Open-Cover Switch Indicator |
| 3. Speed (RPM) Indicator | 10. Unlatch (OPEN)/Latch (LOCK) Knob |
| 4. Time/Hold Mode Switch/Indicator | 11. Imbalance Indicator |
| 5. Timer (Minutes) Setting Switch | |
| 6. Set and Countdown Time Indicator | |
| 7. Brake Switch/Indicator | |

Figure 3-1 Control Panel

The centrifuge cannot be started until the cover is securely closed and latched. The run will continue automatically through the time and braking modes.

NOTE: If power to the instrument is interrupted, the run will automatically be ended to prevent inadvertent start-up when power is restored. The Start button must be pushed again to resume the run after the rotor stops completely.

The green indicator lights when the run begins. This switch also starts or updates (shows original time setting) and starts the timer countdown in the timed mode.

9. Stop-Run/Open Cover Switch Indicator

This momentary-contact pushbutton switch is used to end the run cycle when in the untimed (Hold) mode. It may be used at any time to de-energize the drive motor. When this button is pressed, the rotor decelerates (coasts or brakes) to a stop. This switch is also used to open the cover when the run cycle is over (when the red indicator is lit). There is a five-second interval allowed when the button is pressed to open the cover. For an additional five-seconds press the button again.

10. Imbalance/Indicator

This normally blank red indicator lights only when there is a rotor load imbalance. When this happens the run cycle is terminated and the rotor will coast or brake (if on) to a stop.

11. Unlatch (OPEN)/Latch (LOCK) Knob

This control is used to open or lock the cover. It can only be used when the Power and Stop/Open indicators are lit. Turn the knob one-quarter turn counter-clockwise (CCW) to lock or clockwise (CW) to open the cover.

3.2.2 Dataplate / Power Cord / Fuse

A dataplate which specifies the serial number, power requirements, and other pertinent information is located on the left side of the instrument.

A 3-conductor power line cord at the rear of the instrument is used to connect the instrument to an AC power outlet. Consult the dataplate and Paragraph 2.4.1 for the correct power requirements and connections.

A 10-ampere fuse (8-ampere for 200, 220 or 240 VAC systems) located next to the power cord, provides electrical overload protection for the centrifuge.

Refer to Figure 2-2 for these items.

3.3 OPERATIONAL PRECAUTIONS

1. DO NOT ATTEMPT TO OPERATE THIS CENTRIFUGE BEFORE THOROUGHLY READING THIS MANUAL.

2. Do not operate rotors which do not have a full complement of accessories. Refer to Paragraph 3.4.3.

3. Load and balance all rotors properly. See Paragraph 3.4.3.

CAUTION: This centrifuge is protected from running with excessive imbalance-loading only. Imbalanced loads which may allow running can result in poor separation. For proper operation and insurance against abuse, opposite rotor loads must be balanced in accordance with Paragraph 3.4.3.

4. **CAUTION:** NEVER USE MERCURY IN CUPS OR SHIELDS FOR BALANCING PURPOSES. REFER TO PARAGRAPH 3.4.3.

5. Do not use other manufacturer's accessories in IEC centrifuges unless specified in the Speed, RCF, and Accessory table (Table 3-2). Such misuse of IEC products is potentially dangerous and will void the warranty.

6. Do not block the vent openings on the cover sides or at the bottom of the unit; otherwise air flow will be hampered resulting in poor cooling and early failure of drive motor components. Allow six inches of free space around the instrument.

7. Replace the rotor hex nut securely, even when no rotor is used. This will prevent losing it.

8. Set the POWER Switch to the OFF position when the instrument is not in use.

9. Do not use the centrifugation chamber for storage purposes.

10. Clean the instrument often with mild soap and warm water. **CAUTION:** DO NOT USE ACETONE TYPE CLEANERS.

11. Do not leave cigarettes or other smoking materials on top of the instrument. Lit cigarettes will leave unremovable marks.

WARNING: ALWAYS UNPLUG THE POWER CORD BEFORE REMOVAL OF THE CONTROL PANEL OR GUARD BOWL AS THIS EXPOSES ELECTRICAL SHOCK AREAS WHERE POTENTIALLY LETHAL VOLTAGES ARE PRESENT.

13. NEVER REMOVE THE GROUNDING PRONG FROM THE POWER PLUG, OR USE ANY ADAPTER WHICH DOES NOT COMPLETE THE GROUNDING CIRCUIT.

14. DO NOT ATTEMPT TO OPERATE THE CENTRIFUGE WITH THE CHAMBER GUARD BOWL REMOVED. THE BOWL IS AN IMPORTANT PART OF THE OPERATOR PROTECTIVE STRUCTURE.

15. Biologically infectious materials should be centrifuged only in IEC sealed dome shields (Cat. No. 324). The centrifuge and all components




FIGURE 3-2 INSTALLING ROTOR

must be decontaminated when breakage occurs.

16. This centrifuge is not suitable for use in hazardous locations and it is unsafe to place volatile combustibles in or near the unit.

17. **WARNING — NEVER RERUN THE ROTOR ONCE THE IMBALANCE SWITCH HAS BEEN TRIPPED. INSTEAD, PERFORM A THOROUGH EXAMINATION OF THE LOADING SYMMETRY AND BALANCE.**

3.4 Operating Procedure

Operating procedures include: Installing the rotor, loading the rotor, determining Relative Centrifugal Force (RCF), See Table 3-1, setting the controls, performing the run cycle, and removing the rotor.

3.4.1 Opening the Cover

1. Set the POWER switch to ON. The POWER and STOP indicators will light. Press the STOP/OPEN switch.

2. Turn the open cover knob CW one-quarter turn and open the cover.

NOTE: If there is a power failure, or other emergency, the cover may be opened quickly as described in Paragraph 3.7.

3.4.2 Installing the Rotor

Place the rotor on the shaft. The rotors specified for this centrifuge are secured to the drive motor shaft by a hex nut which is tightened or loosened by means of a wrench, IEC Part No. 1787, which is supplied with the machine. Before placing the rotor onto the shaft, remove the hex nut, then be sure that the tapered hole in the rotor and the taper of

the shaft are clean. Taking care not to damage the threads, carefully lower the rotor onto the shaft, then tighten the hex nut down to secure the rotor to the motor shaft. NOTE: Do not use any other tool to tighten the hex nut as overtightening could occur and the threads could be damaged.

3.4.3 Loading the Rotor

If in normal laboratory use constant vibration is noted, it may be directly traceable to the imbalance of the load in the rotor. The operator should ensure that the rotor is loaded symmetrically and with a full complement of accessories, and that the total-load combination of shields, trunnion rings, cups and/or carriers are all within 0.5 grams of each other. Also check that each shield has a proper cushion and make sure that all shields contain one cushion.

CAUTION: NEVER USE MERCURY IN CUPS OR SHIELDS FOR BALANCING PURPOSES.

It is essential that only IEC rotors, and accessories referenced in the Speed, RCF, and Accessory table (Table 3-2) be used on this centrifuge.

Accessory balance is also an important factor in prolonging the bearing and armature life. IEC rotors, as well as all rotating parts of this centrifuge, are dynamically balanced at the factory. In addition, IEC trunnion rings, shields, cups and carriers are weighed and matched to one-half of a gram. The gram weight is stamped on each piece.

All horizontal and angle rotors should be loaded with a full complement of accessories to prevent unequal stresses on the rotor during operation.

To obtain a good dynamic balance the opposite loads must, in addition to being equal in mass, have the same center of gravity. Care should be taken to select tubes and bottles in pairs that are alike in shape, thickness and distribution of glass or plastic. The larger the container, the more critical the selection should be.

When measuring weight, use a laboratory balance with a sufficient capacity to handle the size container to be used and one which has a sensitivity of one-tenth of a gram at full load.

The following balancing technique renders the best possible weight distribution as well as providing maximum external support for the glassware/plasticware.

1. Place opposite cups containing filled glassware on the balance.
2. To the lighter centrifuge cup, add water around the glassware/plasticware to the level of the liquid in the glassware/plasticware, but no closer to the top of the container than one-quarter inch.
3. Add water to the other centrifuge cup until the two are in good balance.

NOTE: If the use of water is not desired, such as with blood bags, the use of rubber discs, small pieces of soft plastic, or tubing, is suggested.

CAUTION: Mercury should never be placed in cups or shields for balancing.

IMPORTANT: All centrifuges have critical speeds at which vibration occurs. As the speed increases beyond the critical speed vibrations will cease. This inherent condition also occurs during deceleration.

An imbalanced load intensifies these critical frequencies. **DO NOT OPERATE THE CENTRIFUGE CONTINUOUSLY AT OBSERVED CRITICAL FREQUENCIES.**

4. Close and lock the cover. Cover knob must be fully CCW.

3.4.4 Programming the Run Cycle

1. Set the SPEED control to obtain the desired speed. Refer to the Speed, RCF and accessory table (Table 3-2).
2. Set the TIMER to the desired run duration or to the HOLD position if the run is not to be timed.
3. Set the BRAKE control to the desired braking mode or to the OFF (coast) position. This completes the programming of the run cycle.


3.4.5 Starting the Run Cycle

1. Push the START button to begin the run cycle.
2. The rotor will accelerate to the preselected speed, and remain at that speed for the preselected time, and then decelerate according to the preselected braking mode.

3.4.6 Stopping the Run Cycle

The run cycle may be stopped at any time by depressing the STOP button. Otherwise, the instrument will run for the

TABLE 3-1
NOMOGRAPH FOR COMPUTING RELATIVE CENTRIFUGAL FORCE



preselected time and will come to a stop automatically according to the braking mode selected. The STOP indicator will light when the rotor is at rest.

3.4.7 Changing Modes During Operation

Any of the preselected modes, speed, time, or braking may be reset at any time during a run cycle.

3.4.8 Determination of RCF

The relative centrifugal force (G's) may be determined by means of the IEC nomograph which is shown in Table 3-1.

3.4.9 Removing the Rotor

1. Use the IEC Part No. 1787 wrench to loosen the hex nut which holds the rotor to the shaft. Remove the nut by turning it CCW.
2. Use both hands to keep the rotor horizontal and pull the rotor up and off the shaft. If difficulty is encountered replace the hex nut on the shaft and turn down several turns. Use the top of the wrench to lightly tap the hex nut while pulling upward on the rotor to loosen it from the shaft. Remove the hex nut and carefully lift the rotor off the shaft.

3.5 Care and Cleaning of IEC Rotors and Structural Accessories

In order to prevent corrosion and subsequent replacement these procedures should be followed:

3.5.1 Corrosion

An important precaution to be taken by the operator of a centrifuge is to prevent the corrosion of rotors and structural accessories (shields, trunnion rings, cups and carriers). These parts are manufactured by IEC and are properly finished and checked by quality control facilities before they leave the factory. Every possible consideration has been exercised to provide the maximum resistance to corrosion. However, it is essential for proper operation and safety that the operator continue a high standard of preventive maintenance to maintain maximum resistance to corrosion. If corrosion is allowed to continue, small cavities will form within the part which will grow deeper with continuous operation resulting in eventual failure.

3.5.2 Inspection

Before and after each run, the parts should be routinely examined for corrosion and cracks. Particular attention should be given to the inside and bottom of rotor cavities, shields and cups, and to the inside surfaces and corners of rack and multiple type carriers. If these conditions are discovered, discontinue the use of the part immediately and consult IEC.

3.5.3 Prevention

The hazard of corrosion can be completely eliminated by conscientious operator technique. After each run, the part should be rinsed in warm tap

water and finally in distilled water. If material is spilled into the part, it should be washed out with a *mild*, hand-washable liquid detergent solution, and the cavities scrubbed with a stiff test-tube brush having end bristles and a non-metallic tip. The part should be rinsed in warm tap water and finally in distilled water. When particularly caustic materials are run, this procedure should be carried out immediately upon termination of the run.

3.5.4 Drying

After the part has been thoroughly cleansed it is important to dry it properly, preferably by wiping with a clean, absorbent towel. A drying oven may be used, but the temperature should not exceed 80°C. Angle rotors should be stored open to the atmosphere with cavities down, and horizontal rotors turned upside down so that the most surface area is exposed. Shields, cups, and carriers should have their cavities exposed to the atmosphere. Parts should be stored on a soft surface to prevent damage to anodized or other finished surfaces. After the proper cleaning and drying procedures have been followed, store the part clean and dry at room temperature. Parts should not be stored wrapped in a plastic bag.

3.5.5 Corrosion Removal

If surface corrosion occurs, it is of the utmost importance to remove it immediately. The following procedure is recommended.

1. The part should be soaked to remove deposits from the metal surface. Use a 1% mild, non-alkaline, hand-washable liquid detergent solution. Do not use soaps or detergents containing alkalis. Most laboratory detergents are too caustic to use on anodized or lacquered finishes.
2. Scrub the part thoroughly with a stiff

test-tube brush having end bristles and a non-metallic tip. Pay close attention to the bottom of the tube carriers and to multiple carriers.

3. Allow the part to soak again in clear, warm water for a minimum of one hour.
4. Rinse the part thoroughly in warm water first, then rinse it again in distilled water.
5. Dry the part thoroughly with a clean, absorbent cloth.
6. If corrosion is deep and cannot be removed with a tube brush, the unit may be unsafe; discard the item and order a replacement with the same gram weight from your authorized dealer.

3.6 Cleaning the Centrifuge

The centrifuge should be maintained in a clean, uncluttered condition, to insure satisfactory operation and to increase service life. The following procedure is recommended:

1. Unlatch and open the cover to the centrifuge. Remove the rotor.
2. **ALWAYS UNPLUG THE POWER CORD FOR SAFETY DURING CLEANING.**
3. Check the guard bowl for spillage or broken glass. Remove glass with a vacuum cleaner if possible. Remove liquids, and clean the bowl with a damp sponge (See Step 4). Remove rubber cushions in accessories and replace in case of glass breakage. Gray dust is the result of finely-ground glass. This must be removed to insure satisfactory motor life, to prevent sample contamination, and to prevent abrasion of the inside surfaces.

4. Clean the inside of the guard bowl and then the outside of the cabinet, using a moist (not wet) sponge, with warm water and a mild, hand-washable liquid detergent. Repeat using clear, warm water.

NOTE: The guard bowl may be removed from the unit to expedite cleaning.

5. Observe the following precautions at all times:
- (a) Never use an abrasive cleaner or steel wool pads. If there are stubborn stains, remove them with plastic scrub pads.
 - (b) Never pour water into the guard bowl chamber.
 - (c) Do not use strong oxidants, aromatic

solvents, esters, ketones, or chlorinated solvents when cleaning the centrifuge cover.

WARNING: When the cleanup involves hazardous, contaminated or radioactive material, wear rubber gloves and take any other precautions appropriate to the hazards involved. Contact laboratory safety personnel for detailed information.

- 6. Dry the chamber guard bowl thoroughly.
- 7. Wipe the outside of the centrifuge clean and remove any water that may have spilled on the floor.

IMPORTANT

IEC ROTOR DERATING FACTORS vs. SPECIFIC GRAVITY OF ROTOR CONTENTS

All International Equipment Company horizontal and angle rotors are provided with an unlimited operational warranty, excluding mishandling, and never require derating due to hourly or cyclic use provided that corrosion is eliminated and rotor contents do not exceed maximum allowable specific gravity.

Maximum specific gravity permissible without derating is 1.2 in horizontal (swinging bucket rotors) and 1.5 in angle rotors. For specific gravities in excess of 1.2 in a horizontal rotor or 1.5 in an angle rotor, the published speed must be multiplied times the derating factor corresponding to the average specific gravity of the tube plus contents. RPM (allowable) = RPM (Maximum) x derating factor.

The chart below indicates the derating factor for specific gravities from 1.2 to 3.0 in specific gravity increments of .10.

DERATING FACTOR (D.F.)

<u>SPECIFIC GRAVITY</u>	<u>HORIZONTAL ROTORS</u>	<u>ANGLE ROTORS</u>
1.20	---	---
1.30	.960	---
1.40	.925	---
1.50	.894	---
1.60	.866	.967
1.70	.839	.939
1.80	.816	.912
1.90	.794	.888
2.00	.774	.866
2.10	.755	.844
2.20	.738	.825
2.30	.721	.807
2.40	.707	.790
2.50	.692	.774
2.60	.678	.758
2.70	.666	.744
2.80	.654	.731
2.90	.642	.719
3.00	.632	.707

This table is based on the formula:

$$D.F. = \sqrt{\frac{\text{Max. SP. GR. permissible without derating}}{\text{Actual SP. GR.}}}$$

and may be utilized to calculate derating factors for specific gravities greater than 3.0

$$\text{RPM (allowable)} = \text{RPM (Maximum)} \times D.F.$$

3.7 Cover Interlock Mechanical Safety Bypass

This centrifuge protects the user by locking the cover closed during operation. This safety feature may be bypassed only in emergencies such as in a power failure.

- Use a small screwdriver to carefully pry the top corners of the panel out enough to grip the top edge of the panel. Pull the panel off the three upper retaining prongs.
- Lift the panel up enough to clear two retaining tabs at the bottom of the panel.
- Locate the cover interlock release. Use a screwdriver to press down on the release while you turn the knob clockwise. This will release the cover.
- Replace the front panel.

3.8 Guard Bowl Removal/Replacement

Removal: Guard bowl removal will be required for cleaning and for access to certain internal components of the centrifuge.

Remove the guard bowl as follows:

CAUTION: The guard bowl is connected to a chassis ground terminal through an interlock connector. The ground lead is attached to the bottom of the guard bowl and is purposely kept short to require unplugging before allowing the guard bowl to be removed. Therefore, DO NOT attempt to remove the guard bowl completely out of the cabinet until the connector is unplugged.

1. Open the cover and leave it in the open position. Remove the rotor hex nut, all accessories and the rotor. Replace the hex nut.

2. Unplug the centrifuge line cord.

3. Grasp the guard bowl and the rubber gasket around the top edge of the guard bowl. Lift the guard bowl free and out of the housing. The rubber boot will slide off the drive motor upper rubber flange. Carefully place the guard bowl on the edge of the cabinet housing. Unplug the interlock/ground connector. Place the guard bowl aside, taking care that the ground lead and connection are not damaged.





Figure 3-3 Cover Interlock Bypass and Guard Bowl Removal

Replacement

Place the guard bowl on the housing and plug in the ground interlock connector.

1. Grasp the guard bowl by the rubber gasket around the top edge of the guard bowl, and lower it into the housing. Use fingers to assist the rubber boot on seating around the drive-motor upper rubber flange. Close the cover.

2. Plug in the centrifuge line cord.


3.9 Motor Brush Removal and Replacement

1. Remove the guard bowl as described in Paragraph 3.8. Unplug the centrifuge line cord.

2. Identify both brush caps, located on the upper end of the drive motor.

3. Use a screwdriver to remove the brush caps.

Figure 3-4 Brush Replacement



CAUTION WHEN RE-INSTALLING INSPECTED BRUSHES

When brush replacement is not required, it is important that the brush be inserted in the same position as it was removed. The trailing edge of the brush must be positioned as follows (looking from above).



The trailing edge may be identified by the presence of a dark deposit of carbon along that side.

4. Carefully remove the brushes and inspect them. Each brush is complete with a carbon contactor, a spring, a copper connector wire and an end cap. Brush contactors should be replaced when less than 1/4 inch long.

CAUTION: The commutator revolves in a counter-clockwise direction as viewed from above. Replacement of inspected brushes must be inserted in the same position that they were removed to assure long brush life and satisfactory motor operation. The trailing edge of the brush (CCW) may be identified by the presence of a dark deposit of carbon along the side of the brush adjacent to that edge.

5. Inspect the commutator as described in Paragraph 3.10.

6. Inspect the brush to be installed. Use IEC brushes only. Brushes must not be damaged or have broken copper connector wires. The spring should not be fatigued or broken. The brush part number is 49801.

Insert each brush into the holder and align end caps to rectangular slot. Screw in brush caps carefully. Ensure that end caps freely engage the brush holder.

7. Replace the guard bowl as described in Paragraph 3.8.

Important:

When replacing brushes order a spare set.

3.10 Commutator Inspection

Inspect the commutator when brushes are being inspected or replaced, or whenever there is a question as to commutator condition. Use a dial gage to check that maximum commutator radial runout is 0.001". **NOTE:** Severe arcing, with new brushes, is an indication of a bad commutator.

1. Remove the guard bowl as described in Paragraph 3.8.

2. Use a flashlight or an extension light to inspect the commutator through the top ventilating holes of the motor. If the commutator is excessively grooved, or worn, replace the motor.

4.0 SERVICE

4.1 General

This section of the Manual contains instructions for servicing the centrifuge and is intended primarily for the serviceman and the maintenance technician. The section is organized to first present the operating theory, which explains centrifuge operation in terms of its major functions and their interrelationships. The section then presents information on troubleshooting, repair and replacement for purposes of maintenance. Also included are a series of diagrams to assist in understanding the operating theory and as a help in troubleshooting and repair.

4.2 Operating Theory

A simplified diagram of the entire centrifuge system is shown in Figure 4-1 with all the major components and their interrelationships. See also Figure 4-2, the System Schematic Diagram, which shows the electrical interrelationships. Detailed schematic diagrams of the various system elements are also given later in this section as an aid in point-to-point troubleshooting. Each of the paragraphs which follow will consider one specific element of the system, describe its manner of operation, and include the necessary supporting figures.




FIGURE 4-1 SYSTEM FUNCTIONAL DIAGRAM




FIGURE 4-2 SYSTEM SCHEMATIC DIAGRAM




FIGURE 4-2A INTERNATIONAL SYSTEM SCHEMATIC DIAGRAM

4.2.1 Power Circuit

The Power Circuit is shown in Figure 4-3. Input power to the instrument is provided through a three-conductor line cord. The green (green/yellow: international) conductor of the input cable is connected to the instrument chassis ground for operator safety and the black (brown: international) conductor leads to a 12 ampere (8 ampere for 200, 220 or 240 V units) slo-blo fuse for protecting the instrument (and then to Autotransformer T1: international).

The 120 volt line white, black (blue, brown: international) passes through filter Z01 to suppress line interference, and then feeds into Power Switch S10. This switch includes a light which indicates when the switch is ON to show that power is being supplied to the instrument. Line output from the Power Switch is then made available to the Motor Circuit and the +5 Volt Power Supply PS1.




FIGURE 4-3 POWER CIRCUIT

4.2.2 Motor Circuit

The Motor Circuit is shown in Figure 4-4 and the Functional Diagram of Figure 4-5. In these figures, the 120 volt line power feeds to the power distribution points of Splice A and Splice B from the Power Switch as described in Paragraph 4.3. The line to Splice B passes through Guard Bowl Switch E03 which opens to ensure operator safety each time the Guard Bowl is removed. Splice A and Splice B provide power to the Motor B1 and the Motor Fan B2. Power is supplied to Motor Fan B2 only when Fan Relay K1 closes, under the control of a signal from Terminal J/P7 on the Tach/Time Card, to

provide fan operation as determined by the conditions of centrifuge operation.

Splice A and Splice B also provide power to the Motor Control Board which is controlled by the Tach/Time Board as shown in the figures. The function of the Motor Control Board is to bring the motor up to speed where this speed is determined by the setting of Speed Set Switch S6. In addition, still under the control of the Tach/Time Board, the Motor Control Board will keep the motor at this operating speed for a time period determined by the Time Set Switch S5 through the Tach/Time circuits.




FIGURE 4-4 MOTOR CIRCUIT

When the time control circuits in the Tach/Time Board direct the Motor Control Board to bring the motor back to a position of rest, the Motor Control Board enters the COAST mode if Brake Switch S2 is open, or it enters the BRAKE mode if Brake Switch S2 is closed. The BRAKE mode brings the motor to rest in approximately one-third the time of

the COAST mode. A Start Switch S1 is provided to initiate centrifuge operation. The run is terminated either automatically by the Time Set Switch S5, or manually by STOP Switch S4. Actuating the Stop Switch causes the Motor Control Board to enter either the BRAKE or the COAST mode, depending on the position of the BRAKE Switch.




FIGURE 4-5 MOTOR AND MOTOR FAN FUNCTIONAL DIAGRAM

4.2.3 Motor Control Board

The Motor Control Board circuit is shown in Figure 4-6. This figure displays the circuits to and from the Motor Control Board, including wiring details as an aid in point-to-point signal tracing and troubleshooting. Input power comes from Splice A and Splice B, with output shown to Motor B1 through the Choke L02. The Solenoid L01 has the function of locking the centrifuge cover

closed while the motor is in operation. Speed Set S6 is a two-digit thumbwheel switch used to set the desired speed of the centrifuge run. Speed regulation is by a digitally-controlled closed loop system which includes the Motor Control Board, the Motor and the Speed Sensor. This system eliminates the need for calibration and prevents thermal drift of the speed set-point. The Motor Control Board is controlled by the Tach/Time Board through a 14-line cable as shown.




FIGURE 4-6 MOTOR CONTROL BOARD CIRCUIT

4.2.4 Tach/Time Board

The Tach/Time Board Circuit is shown in Figure 4-7. This board controls the Motor Control Board through the 14-line cable as shown. This figure displays the circuits to and from the Tach/Time Board, including the wiring details as an aid in point-to-point signal tracing and troubleshooting. Input power is supplied from the Motor Control Board. Wiring details and theory of operation follow for the controls and circuit devices listed:

START Switch S1	SPEED SET Switch S6
BRAKE Switch S2	IMBAL Switch S7
TIME Switch S3	COVER Switch S8
STOP Switch S4	Fan Relay K1
TIME SET Switch S5	HALL EFFECT Sensor

These controls and circuit devices are discussed individually in Paragraph 4.2.5 which follows. Refer also to Figure 4-8, the System

Wiring Diagram.

4.2.5 Controls and Circuit Devices

4.2.5.1 START Switch S1

START Switch S1 is shown in the Tach/Time Wiring Diagram, Figure 4-7, and in the detailed START Switch Wiring Diagram, Figure 4-9. This switch is located on the front panel of the instrument. This is a normally-open momentary-contact DPST Circuit using the appropriate terminals of a DPDT Switch. Operating the switch will momentarily connect two pairs of contacts on the Tach/Time Board to pulse the associated logic circuits and initiate centrifuge operation. The switch is used only after the SPEED SET Switch S6 and the TIME SET Switch S5 have been set and the braking mode has been chosen by BRAKE Switch S2.





FIGURE 4-7 TACH/TIME CIRCUIT



The internal logic circuits in the Motor Control Board prevent the start of operation if the centrifuge cover has not been securely closed and latched. Once operation starts, the motor will come up to speed. It then continues at that selected speed for the selected length of time, or will continue until STOP Switch S4 is pressed. The motor will then either coast to a stop in the COAST mode, or will brake to a stop in the BRAKE mode, depending on the setting of BRAKE Switch S2. Internal Motor Control Board circuits also protect the instrument by ending the run if power to the instrument should be interrupted for any reason, after which the instrument cannot be restarted until the motor has come to rest. Note that when using the START Switch S1, the green indicator will light to show the run has started. Note also in the Wiring Diagram, Figure 4-9, that the wiring uses terminals on the BRAKE, the STOP, and the TIME Switches as tie points.

4.2.5.2 BRAKE Switch S2

BRAKE Switch S2 is shown in the Tach/Time

Wiring Diagram, Figure 4-7, and in the detailed BRAKE Switch Wiring Diagram, Figure 4-10. The switch is located on the front panel of the instrument. This is a normally-closed SPST Switch Circuit using the appropriate terminals of a DPDT Switch. The switch operates in conjunction with its associated logic circuits in the Motor Control Board. In the normal switch position the instrument is in the COAST mode, the dynamic braking circuit is not active, and the yellow switch indicator does not light. Pressing the BRAKE switch makes the braking action automatically operative when the run is ended and turns on the yellow indicator to show the instrument is in the BRAKE mode of operation. The BRAKE mode will bring the motor to rest in approximately one-third the time of the COAST mode with the total time required for either mode being dependent on the rotor load and the operating speed of the run. Note that the wiring uses one of the STOP Switch terminals as a tie point.




FIGURE 4-9 START SWITCH S1 WIRING DIAGRAM




FIGURE 4-10 BRAKE SWITCH S2 WIRING DIAGRAM

4.2.5.3 TIME Switch S3

TIME Switch S3 is shown in the Tach/Time Wiring Diagram, Figure 4-7, and in the detailed TIME Switch Wiring Diagram, Figure 4-11. The switch is located on the front panel of the instrument. This is a normally-open DPST Switch circuit using the appropriate terminals of a DPDT Switch. The switch operates in conjunction with the logic circuits in the Tach/Time Board by closing two pairs of Tach/Time contacts. In the normal position the timing circuits are active and the yellow indicator does not light. When the TIME Switch is pressed the yellow indicator will light to show that the instrument is set for the untimed mode of operation and that the run will continue until brought to an end by pressing the STOP Switch. In the timed mode, the run will continue for the length of time selected on the TIME SET Thumbwheel Switch. Note that the wiring uses one of the STOP switch terminals as a tie point.

tailed STOP Switch Wiring Diagram, Figure 4-12. The switch is located on the front panel of the instrument. This is a normally-closed, momentary contact DPST Switch using the appropriate terminals of a DPDT Switch. It operates by providing a signal to the Motor Control Board to trigger the logic circuits. The switch may be used at any time to end a run cycle whether the run is a timed run or an untimed run. When this switch is pressed the motor will immediately move out of the RUN mode into the BRAKE or the COAST mode, depending on the setting of the BRAKE Switch. When the motor has come to rest the red switch indicator will light. When the indicator is lighted, pressing the STOP Switch once more initiates a five-second interval for opening the centrifuge cover. The switch may be re-pressed, as needed, in case the cover has not been opened during the first five-second interval. Note that the wiring uses one of the START Switch terminals as a tie point.

4.2.5.4 STOP Switch S4

STOP Switch S4 is shown in the Tach/Time Wiring Diagram, Figure 4-7, and in the de-




FIGURE 4-11 TIME SWITCH S3 WIRING DIAGRAM




FIGURE 4-12 STOP SWITCH S4 WIRING DIAGRAM

4.2.5.5 TIME SET Switch S5

TIME SET Switch S5 is shown in the Tach/Time Wiring Diagram, Figure 4-7. The switch is located on the front panel of the instrument. This switch is a two-digit thumbwheel unit, whose left-most digit reads in ten-minute increments and whose right-most digit reads in one-minute increments. Electrical connections between the switch and the Tach/Time Board consists of four signal lines and two common lines. The four signal lines have values of 1, 2, 4 and 8 respectively while one "common" line is provided for each thumbwheel. Signals from the Tach/Time Board will activate one of the two "common" lines to read the setting of the corresponding thumbwheel. Timer readings are available up to 59 minutes. For longer runs the centrifuge will be operated in the untimed mode of operation.

4.2.5.6 SPEED SELECT Switch S6

SPEED SELECT Switch S6 is shown in the Motor Control Board Wiring Diagram, Figure 4-6. This switch is located on the front panel of the instrument. The switch is a four-digit thumbwheel unit having the two right-most digits set at zero with only the two leftmost digits active for speed settings in the thousands and hundreds of RPM. The switch electrical circuit consists of an "A" and a "B" bank of connections where one bank refers to thousands and the other to hundreds. Each bank consists of a "common" plus four more lines having values of 1, 2, 4, and 8 respectively. The logic circuits in the Motor Control Board respond to the thumbwheel setting to determine the running speed of the motor.

4.2.5.7 IMBALance Switch S7

IMBALance Switch S7 is shown in the Tach/Time Board Wiring Diagram, Figure 4-7, and in the IMBALance Switch Detailed Wiring Diagram, Figure 4-13. This switch is internally located behind the motor assembly. This is a normally-open SPST Switch which closes in case of excessive rotor imbalance as may occur from an improperly loaded run. Switch actuation will close two terminals on the Motor Control Board. When this occurs, the instrument will automatically terminate the run and either brake to a stop or coast to a stop depending on the setting of the BRAKE Switch. At the same time, an IMBALance indication will appear on the panel to alert the operator as to the reason for the

unscheduled termination of the run. Note that the wiring uses three other switch terminals as tie points:- the COVER switch, the STOP switch and the START switch.




FIGURE 4-13 IMBAL SWITCH S7
WIRING DIAGRAM

4.2.5.8 COVER Switch S8

COVER Switch S8 is shown in the Tach/Time Wiring Diagram, Figure 4-7 and in the COVER Switch S8 Detailed Wiring Diagram, Figure 4-14. The switch is located inside the top-front corner of the cabinet. This is a normally-open SPST Switch, so arranged that the switch is "closed" when the cover is closed and "open" when the cover is open. The switch is operated by opening or closing the connection between two contacts on the Tach/Time Board to actuate the corresponding board logic circuits. When the cover is open (switch "open") the instrument may not be started.

4.2.5.9 Fan Relay K1

Fan Relay K1 is shown in the Tach/Time Wiring Diagram, Figure 4-7 and in the Detailed Wiring Diagram, Figure 4-15. The relay is located on the base assembly in the cabinet. Figure 4-15 shows the relay coil circuit: one coil terminal of K1 connects to the +5 Volt Terminal of the +5 Volt Power Supply PS1 and the other coil terminal is fed from a terminal of the Tach/Time Board. This places the fan under the control of the logic circuitry on the Tach/Time Board responding to the operating conditions of the instrument.

4.2.5.10 Hall Effect Sensor

The Hall Effect Sensor is shown in the Tach/Time Wiring Diagram, Figure 4-7 and in the Detailed Wiring Diagram, Figure 4-16. The sensor operating supply is taken from the +5 Volt Terminal of the +5 Volt Power Supply PS1, using one of the Fan Relay K1 terminals as a tie point. In operation, the sensor responds to motor rotation so as to provide the Tach/Time Board with a signal proportional to rotor speed. The speed control circuits in the Motor Control Board use a closed-loop logic circuitry which provides operating accuracy and reliability with resistance to the effects of thermal drift and no need for calibration.




FIGURE 4-14 COVER SWITCH S8 WIRING DIAGRAM




FIGURE 4-15 FAN RELAY K1 WIRING DIAGRAM




FIGURE 4-16 HALL EFFECT SENSOR WIRING DIAGRAM

4.3 Troubleshooting

WARNING:

DANGEROUS AND POTENTIALLY LETHAL VOLTAGES EXIST NEAR THE ADJUSTMENT AND MEASUREMENT POINTS USED FOR TROUBLESHOOTING. USE EXTREME CAUTION WHEN NEAR THESE POINTS.

If trouble occurs it is essential to locate and correct the cause. To locate electrical faults the service technician needs a VOM capable of measuring 250 VAC, 5 and 25 VDC, and resistance.

DO NOT replace components until they have been proven faulty. Rather, take the time to think through what the machine or component should be doing. Use the wiring diagram, and the schematics, and other diagrams in the preceding theory paragraphs


of this manual to help find the source of a problem. If the proper signal or operational activity is not present at a test point, trace the signal back toward its origin to find where the failure first becomes apparent. Frequently, the operating problems are caused by some simple fault such as a loose or open connector. Following through a point-by-point search will find these faults, whereas an indiscriminate replacement of components will often damage the new component if the fault originates elsewhere.

Refer to the Troubleshooting Chart, Table 4-1, for a list of symptoms, possible causes, and suggested remedies.

In case of trouble with a P.C. Board, always check its connectors before deciding replacement is necessary. Field repair of P.C. Boards is not recommended.


TABLE 4-1
TROUBLESHOOTING CHART

SYMPTOM	POSSIBLE CAUSE	SUGGESTED REMEDY
1. No motor operation. Switches do not light	No voltage reaching machine	Check power-outlet and line cord.
	Blown Fuse F1	Check entire machine for loose wires, connectors, or shorts; replace F1 with 8 Amp. fuse (12 Amp. for 120 V).
	Open Wiring	Check point to point.
	Defective Switch	Check S10 (black lead) for 120/240 VAC with reference to neutral.
2. No motor operation	Improper Operation	Check that the cover is properly closed and that panel controls are properly set.
	Defective Interlock (Door Switch S8)	Check Door Switch S8 by manual operation and ohmmeter check. Trace 120/240 volts through S8 to timer terminal.
	Defective Timer Switch	Check with ohmmeter and replace if defective.
	Defect in Motor	Check continuity of Switch S8. Unplug machine. Check brushes. Clean brushes, brush holders, and commutator. Plug machine in. Observe if voltage is applied when run button is pushed (be sure interlock is closed).
	Open Windings	Check continuity with ohmmeter.
	Defective Component on Motor Control P.C. Board	Replace P.C. Board
3. Abnormal motor control	Speed Switch S6 Faulty	If control is normal at some positions, and abnormal at others, replace the switch.
	3a. No, or erratic, speed display while motor is turning. Cover may be opened during run.	Defective Speed Sensor Check connector J/P1. Check that tach pulses are present on J/P1-19 with respect to ground. If tach pulses are present, but still no reading, replace the Tach/Time P.C. Board.
4. Braking action erratic or inoperative	Defective Brake Switch S2 or Motor Control P. C. Board	Check Brake Switch S2 with ohmmeter and replace if defective. Replace Motor Control P. C. Board.
5. Timing action erratic or inoperative	Defective Timer Switch S5, or Tach/Time P.C. Board, &/or connections.	Observe Timer Switch S5 operation during use and replace if defective. Replace Tach/Time P.C. Board.
	Defective Relay Contacts on K1	Check with ohmmeter and replace if defective.
6. Electrical shock when touching case during operation	Improper or defective power line or power socket	Power line must be a properly grounded 3-wire line. Use with 2-wire adapter is not recommended and can be dangerous.
	Internal grounding wire loose or disconnected	Check that grounding wires are all in place and tightened.



HIGHEST COMPONENT REFERENCE DESIGNATION USED
R14 C16 CR7 U6 JMP303 D6 L2

NOTES:
1. UNLESS OTHERWISE SPECIFIED:
ALL RESISTORS ARE 1/4 W 5%
ALL CAPACITORS ARE 10V MIN.



DAKON/IEC DIVISION	
DATE	SCHEMATIC, P.C. BD. DISPLAY
REV	105 2
D	10

FIGURE 4-17 DISPLAY P. C. BOARD SCHEMATIC



INTERNATIONAL EQUIPMENT COMPANY

A DIVISION OF DAMON

300 SECOND AVE., NEEDHAM HTS., MASS 02194 TEL (617) 449-0800
TELEX 92-2499, INTLEQUIP NEDM CABLE INTERCO-BOSTON